


# HEXAGON RGB WALL PANELS INSTRUCTIONS Cut Line

Material: 105gsm double side art paper (C2S).  
Color: Black + pantone cool gray 8c  
Surface coating : glossy varnish.

6.25 INCHES

## ATRIX HEXAGON RGB WALL PANELS USER GUIDE



7.75 INCHES

### Need Help?

Have any questions or comments? Need help getting set up?  
Contact us at <https://care.gamestop.com>

### What's Included

- 6 Hexagon RGB Wall Panels
- USB Boards
- Triangle Fasteners
- Double-Sided Adhesive Pads
- Plastic L Shape Stand
- LED Light Remote Control (CR2025 Battery Included)
- USB-A to USB-A Power Cable

### Mounting the Wall Panels

- Ensure the mounting surface is clean, smooth, and free of any loose debris or dust.
- Attach 6 double-sided adhesive pads to the back of the hexagon RGB wall panels.
- Remove the double-sided adhesive backing on pads when wall panels are ready to be placed on the wall.
- Insert USB boards to connect the wall panels. Build a design of your choice. Note: Keep the arrow in the middle of the USB board facing you.
- Insert triangle fastener into the holes of wall panels to keep the unit sturdy.
- Firmly press the wall panel to the wall, pressing the middle of wall panels, until it is fully fixed.
- Plug the USB-A end of the included power cable into the side of the unit and the opposite end into a USB power supply of at least DC 5V 2A.

### Using the Stand

- Set up wall panels, triangle fasteners, USB boards, and power cable as noted in the "Mounting the Wall Panels" section.
- Select one of the 6 wall panels that is near the bottom of the table and attach an adhesive pad on the back.
- Remove the two protective films from the L stand, and attach the longer side of the L stand to the back of wall panel.
- Firmly press the L stand to the wall panel until it is fully fixed. Then place the RGB wall panels on a sturdy flat surface.

### Using the Remote

- The remote is already connected to the lights. Use it to select colors, strobe, light brightness and more.
- When using the remote for the first time be sure to remove the protective film from the battery. The remote uses CR2025 batteries, if it is not working replace the battery.

### Removing the Wall Panels

- Remove the panel, and pull the adhesive pads up from a corner. Note: The adhesive pad may leave residue on the wall, it should wipe away with no issues. They also may remove pigment from certain paints.
- The adhesive pad is suitable for wall tiles, painted wood, metal, or smooth surfaces.

Model: GSSK10 Input: DC5V±5% 1.2A Made in China

#### Important Safety Instructions

**WARNING** When using this product, basic precautions should always be followed, including the following:  
Read these instructions carefully.  
All cautions and warnings should be followed.  
Protect equipment from humidity.  
Do not use chemical detergents to clean your device, use a soft dry cloth.  
Do not connect more than 12 pcs RGB wall panels to the USB cable. If you need to use 12pcs RGB wall panels, please make sure the input of USB power supply is at least DC 5V 2.4A.  
To avoid damage from electrical peaks unplug the device when it is not in use.  
If one of the following situations arise, equipment has to be checked by qualified service personnel:

- Liquid has penetrated into the equipment.
- Equipment has been exposed to humidity.
- Equipment has been dropped and/or is damaged.
- Equipment has obvious sign of breakage.
- Equipment does not work well or you cannot get it working according to user's manual.

#### SAVE THESE INSTRUCTIONS

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### WARNING

**Chemical Burn Hazard** Keep batteries away from children. Do not ingest the battery.

#### Chemical Burn Hazard

The remote control supplied with this product contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death. Keep new and used batteries away from children. If the battery compartment does not close securely, stop using the product and keep it away from children. If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

#### Battery Warning Statement

Insert the battery in the proper direction as indicated by positive (+) and negative (-) markings in the battery holder. Remove a depleted battery promptly and recycle or dispose of it in accordance with Local and National Disposal Regulations. If a battery leaks, remove it and recycle or dispose of it in accordance with battery manufacturer's instructions and Local and National Disposal Regulations. If fluid from the battery comes into contact with skin or clothes, flush with water immediately. Remove the battery if you device is to be stored for an extended period of time without being used.

ATRIX, Geeknet, Inc. 625 Westport Pkwy, Grapevine, TX 76051 Phone: 855-474-7717

FRONT