

PORTABLE GREEN SCREEN INSTRUCTIONS Cut Line

Material: 105gsm double side art paper(C2S).
Color: Black + pantone cool gray 8c
Surface coating : glossy varnish.

6.25 INCHES


ATRIX PORTABLE CHAIR MOUNTING GREEN SCREEN USER GUIDE

What's Included


- Chair Mounting Green Screen
- Carrying Bag

Repacking the Green Screen


- **Step 1** - First remove the green screen from the top of your chair.




- **Step 4** - Hold the top curve of a half-circle, and fold another side of the green screen from 1/4 position into the center of the half-circle.



- **Step 2** - Hold two sides of the green screen; folding away from you, fold the green screen in half.



- **Step 5** - Make sure the small circle you just folded is in the center of the green screen, there will be three circles. Adjust them until they are the same size.




Make sure the small circle you just folded is in the center of the green screen, there will be three circles.


Need Help?

Have any questions or comments? Need help getting set up?
Contact us at <https://care.gamestop.com>

- **Step 3** - Rotate the green screen so you are holding it from the top curve of the half-circle.



- **Step 6** - Place folded green screen into the carrying bag.



ATRIX | Geelnet, Inc. 625 Westport Pkwy, Grapevine, TX 76051 Phone: 855-474-7717

4.5 INCHES

FRONT