

4.25 INCHES

ATRIX. ? S-SERIES HEADSET USER GUIDE

PS4 Setup

- Plug the headset into the controller.

 Your headset may automatically switch to your output depending on your PS4 settings.
 If it doesn't switch, enter the Settings Menu > Devices > Audio Devices.
 Set input and output device to "Headset Connected to Controller."
 Change "Audio Output to Headphones" to "All Audio."
 Set headphone volume level to your desired setting.
 Select the microphone level and follow the prompts to adjust your desired settings.

XBOX Series X/S

- Plug the headset into the controller.
 Note: Not all controllers will have a 3.5mm audio jack.
 Your headset may automatically switch to your output depending on your XBOX Series X/S settings.
 Enter the Setting Menu > General Settings > Audio Output > Other Opitions > Mute driver in display.
 Set headset volume to your desired setting.
 Set mic monitoring to your desired setting.

XBOX ONE Setup

- Plug the headset into the controller.
 Note: Not all controllers will have a 3.5mm audio jack.
 Your headset may automatically switch to your output depending on your XBOX ONE settings.
 Enter the Setting Menu > General Settings > Audio Output > Other Opitions > Mute driver in display.
 Set headset volume to your desired setting.
 Set mic monitoring to your desired setting.


Switch Setup

Plug the headset into the switch. The switch must be used out of the dock in handheld mode to use the audio jack.

PC/Laptop Setup

- Plug the headset into your PC's audio jack. Not all computers will be able to be use the microphone without the use of an
- Make sure the system you are using supports a 3.5mm audio headset jack.

Rotating the Mic



The mic rotates up and down and is easily adjusted. Press it up or down to help adjust how much volume it can pick up.