Material: 105gsm double side art paper( C2S). Color: Black

Surface coating: glossy varnish.

# 6.25 INCHES

# Check Power 0000

ATRIX AK POWER BANK USER GUIDE

### Need Help? Important Safety Instructions

# ⚠ WARNING

When using this product, basic precautions should always be followed, including the following:

Power Indicator

- · Read all of the instructions before using the product.
- · To reduce the risk of injury, close supervision is
- necessary when the product is used near children.
- Do not put fingers or hands into the product. Do not expose power bank to rain or snow.
- · Use of a power supply or charger not recommended or sold by the power bank manufacturer may result in a risk of fire or injury to persons.
- · Do not expose to fire or excessive temperatures.
- Exposure to fire or temperature above 212°F (100°C) may cause the power bank to explode.

Model: PC861 Input: 5V = 1.0A Output: 5V = 2.1A Battery Capacity: 3.7V/4000mAh/14.8Wh Power Bank

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

by the party responsible for compliance could void the user's

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

USB-A to Micro USB Charging Cable

Charge Output/

USB-A port

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- · Increase the separation between the equipment and receiver
- · Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- · Consult the dealer or an experienced radio/TV technician
- for help

Made in China

Charge Input/ Micro USB port

6.25 INCHES

# Capacity: 2300mAh

## 

Changes or modifications to this unit not expressly approved authority to operate the equipment.

of the FCC Rules. These limits are designed to provide

Geeknet, Inc. 625 Westport Pkwy, Grapevine, TX 76051 Phone: 855-474-7717

# · A fully charged power bank will last 6 months minimum when not in use. In order to increase the longevity of your power bank, it is recommended that it is used regularly and charged when the power bank has been

Have any questions or comments? Need help getting set

· Plug the USB end of the charging cable specific to your

device into the power bank, and the charging tip into

· The LED indicator will display the amount of power

remaining as the power bank charges your device.

· The power bank takes 5 hours to charge, but may take

· Using the cable provided, plug into a UL Compliant USB

LED Charge Indicator: • 25% •• 50% ••• 75% •••• 100%

up? Contact us at https://care.gamestop.com

· USB-A to Micro USB Charging Cable

(this cable does not transfer data)

Charge The Power Bank

power supply of at least DC 5V/1A.

**Charge Your Device** 

What's Included

• 4000 mAh Power Bank

vour device.

longer.