

6.25 INCHES

ATRIX. ⚡ SNIPER KEYBOARD USER GUIDE



5.4 INCHES

What's Included

- RGB Sniper Gaming Keyboard

Need Help?

Have any questions or comments? Need help getting set up?
Contact us at <https://care.gamestop.com>

Light Function Keys

- FN Key + INS - Cycle 14 preset keyboard light settings
- FN Key + DEL - Cycle 9 solid color light settings
- FN Key + PB - Reset keyboard light settings
- FN Key + PS - Turn off keyboard lights
- FN Key + ESC - Reset to factory settings
- WIN + L - Lock/Unlock Windows Key
- FN Key + Up Arrow - Increase Brightness
- FN Key + Down Arrow - Decrease Brightness
- FN Key + Left Arrow - Decrease LED Speed
- FN Key + Right Arrow - Increase LED Speed

Custom Light Settings

- To set custom light settings press FN+1 at the same time followed by FN+HM to start recording.
- Select the keys that you want to be active in this light mode.
- Press FN+HM to finish recording.
- There are 5 custom light settings. To record another press FN+2, FN+3, FN+4, or FN+5 and follow the steps above.
- To activate press the FN+the desired light setting.

Keyboard Multimedia Keys

- | | |
|--------------------------------|------------------------------|
| • FN Key + F1 - Computer | • FN Key + F2 - Calculator |
| • FN Key + F3 - Search | • FN Key + F4 - Media Player |
| • FN Key + F5 - Previous Track | • FN Key + F6 - Next Track |
| • FN Key + F7 - Play/Pause | • FN Key + F8 - Stop |
| • FN Key + F9 - Mute | • FN Key + F10 - Volume - |
| • FN Key + F11 - Volume + | |

Important Safety Instructions

WARNING When using this product, basic precautions should always be followed, including the following: Read these instructions carefully. All cautions and warnings should be followed.

- Protect equipment from humidity. • Do not use chemical detergents to clean your device; use a soft dry cloth. • To avoid damage from electrical peaks unplug the device when it is not in use. If one of the following situations arise, equipment has to be checked by qualified service personnel:
- Liquid has penetrated into the equipment. • Equipment has been exposed to humidity. • Equipment does not work well or you cannot get it working according to user's manual.

SAVE THESE INSTRUCTIONS

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the manufacturer's instruction, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Made in China

ATRIX. Geeknet, Inc. 625 Westport Pkwy, Grapevine, TX 76051 Phone: 855-474-7717

FRONT