



6.25 INCHES

ATRIX 23W WALL CHARGER USER GUIDE



Need Help?

Have any questions or comments? Need help getting set up?
Contact us at <https://care.gamestop.com>

What's Included

- Wall Charger

USB-A Out Port

- The wall charger has a USB-A port capable of charging devices like headsets, phone, and more through your USB-A charge cable.

USB-C Out Port

- The Type-C port can be used on devices like headsets, powerbanks, and phones at high speeds

power indicator

- Plug the wall charger into a grounded wall outlet. The power indicator light will turn white if it is working properly.

Important Safety Instructions

Read this instructions carefully.
Keep this instructions for later reference.
All cautions and warnings should be followed.
The equipment shall be used at maximum 25°C ambient temperature.
Do not open the equipment to reduce the risk of electrical shock. For safety reasons it is only allow to be opened by qualified service personnel.
Protect equipment from humidity.
Equipment has to be protected from objects falling through or liquids dripping through the openings. This could cause a fire or electrical shock.
Disconnect equipment from power supply before cleaning. Do not use any liquid or aerosol cleaner. Use only moistened cloths.
If the equipment is not used for long time, disconnect the equipment from power supply to avoid being damaged by voltage peaks or lightning strike.

If one of the following situations arise, equipment has to be checked by qualified service personnel

- Liquid has penetrated into the equipment.
- Equipment has been exposed to humidity.
- Equipment has been dropped and/or is damaged.
- Equipment has obvious sign of breakage.
- Equipment does not work well or you cannot get it working according to user's manual.

The equipment shall not be exposed to dripping or splashing and no object filled with liquids, such as vases, shall be placed on the equipment.
Where the mains plug is used as the disconnect device, the disconnect device shall remain readily operable.
The socket-outlet shall be installed near the equipment and shall be easily accessible.

SAVE THESE INSTRUCTIONS

Model Number: PYS-WAC20038-02 AC charger Input: AC 100-240V~50/60Hz 0.7A Max Output: USB-C: DC 5V 500mA, DC 2V 500mA, DC 5V 500mA USA, USB-A: DC 5V 500mA

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to radio communications. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Made in Vietnam

ATRIX Geeknet, Inc. 625 Westport Pkwy, Grapevine, TX 76051 Phone: 855-474-7717

5.4 INCHES

FRONT